



BOOT SEAL FITTING INSTRUCTIONS FOR EJ-EH-HD-HR-HK-HT-HG-HQ-HJ-HX-HZ-WB & LH-LX-UC TORANA

Before fitting this seal please carefully read these instructions as follows:

1. Check Your Seal to find where it is joined. In most cases, the clips at this point are closer together than the rest. This is your starting point.
2. In most cases, your boot lid will also have two holes closer together than the rest. This is your starting point.
3. Ensure you are fitting the seal the correct way as shown on the illustration below.

If you follow these three steps you should not have any problem fitting your seal!

