



FITTING DOOR APERTURE SEALS

Tools you will need:

- Rubber Mallet
- Side Cutters or Large Scissors.

1. Check the replacement seal is a similar type of seal, and is similar in size and length to the original.
2. Position one end of the Pinchweld at your selected start point and using the palm of your hand, or a rubber mallet, push into place
3. Cut the new seal to length once it is in place, and superglue the two ends together.

WARNING: Pinchwelds do shrink with age, so do not stretch into place. Pack tightly into corners and leave surplus if possible, under the door scuff plates.

